



Please use this template to mark out and drill pilot holes:

- For timber Ceilings: 4x  $\phi$ 7mm(1/4") holes, 70mm (2.75") deep.
- For masonry ceilings: 4x  $\phi$ 12mm(1/2") ,70mm (2.75") deep.



ATDEC Pty. Ltd.  
Level 1, 26 Castlereagh St  
Liverpool NSW 2170

Tel: +61 2 8729 5000  
Fax: +61 2 8729 5050

www.atdec.com

PROPRIETARY AND CONFIDENTIAL  
THIS DOCUMENT REMAINS THE PROPERTY OF ATDEC PTY. LTD.  
AND MUST NOT BE COPIED WITHOUT OUR EXPRESS WRITTEN  
PERMISSION AND THE CONTENTS THEREOF MUST NOT BE  
IMPARTED TO ANY THIRD PARTY NOR BE USED FOR ANY  
UNAUTHORISED PURPOSE.

TITLE:

Drilling Template

PART NO: TH-1040-CTL/S

ALL DIMENSIONS IN MILLIMETRES  
DO NOT SCALE

GENERAL TOLERANCES:  
LINEAR:  $\pm 0.2$ mm  
ANGULAR:  $\pm 1^\circ$

SCALE: 1 : 1  
SHEET: 1 OF 1

DRAWN: JH  
DATE: 13/02/2012

Aprvd:  
CHK'D:

A4

DWG NO.  
DWG-PCM-001-TEM

NOTES:

1. This template is only for the product TH-1040-CTS and TH-1040-CTL
2. General Tolerances:  $\pm 0.2$  mm
3. All Dimensions Symmetrical About Centreline U.N.O

REV	DATE	REVISION	BY
REV A	00.00.00	First Issue	
ISSUE	DATE	REVISION	BY